

# full parts breakdown...

## fluid Duo Siphonic Two Piece Toilets

The following is a part breakdown for all versions of the fluid Duo.  
The only difference refers to the flush setting the tank is set to be.

**301502W (R)**

Duo Toilet Bowl

**301548W (R)**

4.8 lpf/1.28 gpf Duo Tank

**301538W (R)**

3.8 lpf/1.0 gpf Duo Tank

Limited Edition Duo Tank

**301500W (R)**

3 lpf/0.8 gpf Duo Tank



### Outlet/Flush Valve

(The part inside a toilet tank that brings water from the tank into the bowl and initiates the flush)

**Consists of Base + Head.**

### Tank Lid

301548-LID\*



### Inlet/Fill Valve

A1280

(The part inside a toilet tank that fills the tank with water and prevents water from overflowing)

### Dual Flush Lever Handle

A2436060300-C (Left Lever)

A2436060400-C (Right Lever)

### Bolt Cover Caps

687243W

### Soft Close Seat

326203W

**Consists of Seat + Fixing Kit**



# full parts breakdown...


## fluid Duo Siphonic Tanks

The only difference between the fluid Duo tanks are the flush settings shown below.


**Note:** Each outlet valve is clickable and links to the parts store.



### Duo Outlet Valve Settings




### Replacement Outlet Valve Heads



\* For right lever tanks (-R)

# full parts breakdown...

## fluid Duo Siphonic Two Piece Toilets



**Inlet/Fill Valve**

A1280

**Outlet/Flush Valve**

- A2436-G-301548W
- A2436-G-301538W
- A2436-G-301500W

## Shop More Toilet Repair & Maintenance Parts:

